

# FOAM ELIMINATOR

## DEFOAMER



### Technical Data

#### Specifications

<b>Color:</b>	Clear
<b>Odor:</b>	Characteristic
<b>Base:</b>	Silicone emulsion
<b>pH:</b>	7.4 + 0.5
<b>Viscosity:</b>	Slight viscous
<b>Foam:</b>	None
<b>Phosphate:</b>	None
<b>Flash Point:</b>	None
<b>Storage/Stability:</b>	1 year
<b>Weight Per Gallon:</b>	8.33 lbs
<b>Freeze/Thaw Stability:</b>	Keep from freezing

#### Description

Convenient ready-to-use formula, just add 2 to 4 oz. per recovery gallon. Eliminates foam in recovery tanks of extractors, automatic shampooing equipment, wet vacuums, and floor scrubbers. Protects motors from damaging foam build-up.

#### Directions

Read all directions and cautions on the label prior to using. Consult the MSDS for recommended personal protection equipment.

Shake well before using. Add 2 to 4 ounces per gallon capacity of the recovery tank of extraction machines, wet vacuums and automatic scrubbers. For additional foam control, spray inside walls of recovery hose and recovery tank. Do not apply directly to floors.

#### What the Pros Know

Never add Foam Eliminator directly onto the carpet or hard surface, only into recovery tanks.

**Eliminates Foam Build-Up in the Recovery Tank**

**Protects Motors**

